


# Upgrading firmware

Note: To prevent data loss, it is recommended that you backup your data to another location before upgrading the firmware of your DrivePro 250.

1. After downloading firmware from Transcend website, decompress it and then put **"FWDP5551.bin"** in the **"SYSTEM"** folder in microSD memory card.



2. Insert the microSD memory card that contains a newer version of firmware.
3. Connect the DrivePro to an external power outlet. Do NOT remove the USB cable while the firmware is being upgraded.
4. Select Upgrade Firmware from the "Settings" menu and press  to start the firmware detection process. The DrivePro will automatically find the new firmware file.